


FTDI_R board to VNC1 board connection



A three wire cable for Gnd,Tx and Rx connection for normal use.
if required, the Cts / Rts can be connected